

Dilution Control Systems

Multi-Task
Easy Fill Model 421720

OPERATION

SERVICE

PARTS

CARE



Multi-Clean[®]
Your Guide to Clean

Easy Fill Gun model 421720

THANK YOU FOR YOUR INTEREST IN OUR PRODUCTS

Please use this equipment carefully and observe all warnings and cautions.

***** NOTE *****

WEAR protective clothing and eyewear when dispensing chemicals, emptying equipment or changing metering tips.

ALWAYS observe safety and handling instructions

ALWAYS direct discharge away from you or other persons or into approved containers.

ALWAYS dispense cleaners and chemicals in accordance with instructions.
Exercise **CAUTION** when maintaining your equipment.

KEEP equipment clean to maintain proper operation.

ALWAYS re-assemble equipment according to instruction procedures. Be sure all components are firmly screwed or latched into position.

ATTACH only to tap water outlets (25 PSI minimum, 85 PSI maximum).

Easy Fill Gun Set Up Instructions

1. Remove all parts from carton.
2. Connect supply hose to water spigot.
3. Thread product bottle onto gun.
4. Turn water supply on at spigot.
5. Place discharge hose in container to be filled and squeeze trigger to start filling.
6. Supply hose must be disconnected from Easy Fill Gun after each use (Fig 3).



Figure 1

Easy Fill Gun Operating Instructions

1. Place discharge hose in container to be filled and press trigger down to turn on.
2. To fill large containers, lock trigger on by sliding lock forward while in the on position.
3. When product container is empty, thread gun from container and attach gun to new container.



Figure 3



Figure 2



Figure 4



600 Cardigan Road
Shoreview, Minnesota 55126
Phone 651-481-1900
www.multi-clean.com

988442
Printed in U.S.A.