

Dilution Control Systems

Multi-Fresh Touch Free Dispenser Stand Model 421910

OPERATION

SERVICE

PARTS

CARE



Multi-Fresh Touch Free Dispenser Stand 421910

THANK YOU FOR YOUR INTEREST IN OUR PRODUCTS

Please use this equipment carefully and observe all warnings and cautions.

***** NOTE *****

ALWAYS observe safety and handling instructions

ALWAYS direct discharge away from you or other persons or into approved containers.

ALWAYS dispense cleaners and chemicals in accordance with instructions.
Exercise **CAUTION** when maintaining your equipment.

KEEP equipment clean to maintain proper operation.

ALWAYS re-assemble equipment according to instruction procedures. Be sure all components are firmly screwed or latched into position.

Dispenser Instructions

1. Open the dispenser cover, insert key into slot at the top of the dispenser.
2. Take Engine/Battery Assembly out, first remove the refillable bottle, then depress the engine lock tab above of assembly and pull assembly up.
3. Mount the dispenser using the provided Top and Bottom Mounting Screws through the Back Plate and into the 1" x 54" Square Tube.
4. Attach 1" x 54" square tube to the base using the provided 1/4 x 20 x 1" Bolt.
5. Attach Engine to Back Plate.
6. Slide the battery cover open located on the right side of the unit.
7. Install batteries in the proper direction. (4-C cell alkaline batteries required)
8. Replace battery cover by inserting notches at an angle and snap into place.
9. Attach Base to bottom of Tube with 1/4-20 x 3/4 flathead bolt.
10. Replace refillable bottle.
11. Open Cartridge Fill Cap and fill with sanitizer.
12. Close cover.
13. Place stand in traffic area where it is convenient to use.

Troubleshooting Touch Free Dispenser:

Slow flashing green - standby mode, indicates dispenser is working properly.

Rapid flashing green - dispenser is delivering soap or the sensor is interrupted by an obstacle.

Slow flashing red - batteries require replacement.

Multi-Fresh Touch Free Dispenser Stand 421910




Figure 1

Multi-Fresh Touch Free Dispenser 421858




Figure 2

LIMITED WARRANTY

Multi-Clean Division warrants to the original purchaser/user that this product is free from defects in workmanship and materials under normal use and service for a period of 90 days from date of purchase. In addition, Multi-Clean Division will, at its option, honor labor warranty claims for the first 90 days from date of sale, provided such claims are submitted through and approved by factory authorized repair stations. Multi-Clean Division will, at its option, repair or replace without charge, except for transportation costs, parts that fail under normal use and service when operated and maintained in accordance with the applicable operation and instruction manuals.

This warranty does not apply to normal wear, or to items whose life is dependent on their use and care, such as belts, cords, switches, hoses, rubber parts, electrical motor components or adjustments. Parts not manufactured by Multi-Clean Division such as engines, batteries, battery chargers, hydraulic pumps, and tires are covered by and subject to the warranties and/or guarantees of their manufacturers. Please contact Multi-Clean Division for procedures in warranty claims against these manufacturers.

Special warning to purchaser — A potential health hazard exists without exact original equipment replacement.

All warranted items become the sole property of Multi-Clean Division or its original manufacturer, whichever the case may be.

Multi-Clean Division disclaims any implied warranty, including the warranty of merchantability and the warranty of fitness for a particular purpose. Multi-Clean Division assumes no responsibility for any special, incidental or consequential damages.

This limited warranty is applicable only in the U.S.A. and Canada, and is extended only to the original user/purchaser of this product. Customers outside the U.S.A. and Canada should contact their local distributor for export warranty policies. Multi-Clean Division is not responsible for costs or repairs performed by persons other than those specifically authorized by Multi-Clean Division. This warranty does not apply to damage from transportation, alterations by unauthorized persons, misuse or abuse of the equipment, use of non-compatible chemicals, or damage to property, or loss of income due to malfunctions of the product.

If a difficulty develops with this machine, you should contact the dealer from whom it was purchased.

This warranty gives you specific legal rights, and you may have other rights which vary from state to state. Some states do not allow the exclusion or limitation of special, incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you.