

# Hand Hygiene Station

**One Pump Will Sanitize Hands from Harmful Germs and Viruses**

**Use Only When Hands Are Not Visibly Soiled**

**Foaming Hand Sanitizer Directions:**



**Dispense one pump into palm**



**Apply to all surfaces of hands**



**Rub until dry**



This wall chart and mounting template is designed to make it easy to mount a foaming hand soap dispenser to a wall and to attract attention to the need for proper and frequent hand hygiene.

**Directions:**

1. Attach template to wall temporarily with adhesive tape so the bottom is no more than 54 inches from the floor, to comply with ADA guidelines.
2. Use a sharp object such as a tack or nail to mark the hole locations. Remove template.
3. Drill 15/64" holes at marks, insert anchors. Replace template and insert screw through template into anchors. Screw in so the head of the screw is 1/4" out from the wall. Hang dispenser.
4. Tighten screws.



Optional: You may also mount the dispenser using adhesive tape instead of screws. In this case, you must cut out green areas of the template.