

PREPARATION

1. Gather all items to be cleaned: and place on dashboard "A".
2. Flush, scrape and, preclean items to be washed.
Scrape debris and food into trash receptacle.
3. Sinks must be clean before use.

FILL SINKS

4. Turn on water supply to SINK STATION dispenser and adjust water temperature to warm.
5. Fill **Wash** basin to the desired level with 15 Power Suds.
Drain and refill as needed.
6. Fill **Sanitize** basin to desired level with 10 M-C Sanitizer.
7. Fill **Rinse** basin with warm potable water, drain and refill with fresh water as needed.

WASHING & SANITIZING

8. Thoroughly wash all items in **Wash** basin.
9. Allow soapy water to drain off and move items to **Rinse** basin.
10. Move items to **Sanitize** basin. Allow items to soak for 1 minute.
11. Place items on drying rack "B" to air dry. Do not re-rinse or towel dry.
12. Change M-C 10 Sanitizer solution periodically to assure effective sanitizing. Sanitizer test strips should read 200 - 400ppm.



15 Power Suds

Foaming hand dishwashing detergent. Item 902863

10 M-C10 Sanitizer

No rinse sanitizer. Item 902803

SDSs Online www.multi-clean.com

Proper Operation Checklist

- Turn water valve to full ON position.
- Prime dispenser by filling and emptying container until tubing fills with concentrate.
- Caps should be firmly screwed on to chemical concentrates.
- Avoid any "kinking" of hoses leading from concentrate containers.

3 Cuenca del Fregadero Para Lavar Platos Procedimiento

PREPARA


1. Se reúnen todos los elementos para ser limpiados: y el lugar en dashboard "A".
2. Ras, y raspar, pre artículos limpios para ser lavados.
Raspe los residuos y los alimentos en el recipiente de basura.
3. Fregaderos deben estar limpios antes de su uso.

Llenar los Sumideros

4. Abra el suministro de agua en SINK dispensador ESTACIÓN y ajustar la temperatura del agua se caliente.
5. Llenar Lavabo al nivel deseado con 15 Suds de energía.
Escalar y rellenar si es necesario.
6. Relleno de la cuenca del desinfectante al nivel deseado con 10 M-10 C desinfectante.
7. Llenar cubeta de enjuague con agua potable caliente, drene y rellene con agua dulce como sea necesario.

Lavado y Desinfección

8. Es necesario lavar todos los elementos de lavabo.
9. Permitir que el agua jabonosa para drenar y mover elementos para enjuagar cuenca.
10. Mover elementos a desinfectar cuenca. Permita que los artículos en remojo durante 1 minuto.
11. Coloque los artículos en tendedero "B" se seque al aire. No vuelva a enjuagar o secar con una toalla.
12. Cambie M-C10 solución desinfectante periódicamente para asegurar una desinfección eficaz. tiras de prueba de desinfección deben leer 200 - 400 ppm.



15 Power Suds

La formación de espuma de detergente para lavar platos a mano.

10 M-C 10 Sanitizer

No se enjuague desinfectante.

SDSs Online www.multi-clean.com



Quat Tiras de prueba
Item 421200

Lista de comprobación correcta operación

- Girar la válvula de agua a la posición a tope.
- El primer dispensador de llenado y vaciado recipiente hasta que el tubo se llena con concentrado.
- Los tapones deben estar firmemente atornillados a concentrados químicos.
- Evitar cualquier "retorcimiento" de las mangueras que lleva de los recipientes de concentrado.